

# EBS-630A Fixed-Impedance/Voltage Ceiling Speaker

Thank you for purchasing EBS-630A Fixed-Impedance/Voltage Ceiling Speaker. In order to correctly use the device, please read the manual carefully.

If you have any questions or suggestions, please contact our local dealer.

#### Features

- Professional, passive, two-way, full-range, fixed-impedance/voltage ceiling speaker that can be embedded or suspended. Utilizes ABS panel + metal cabinet, all-weather-proof material against moisture, water, and UV.
- One 6.5" woofer with moisture/water-proof composite diaphragm, and 1" silk-dome tweeter with adjustable angle, producing rich mids, delicate highs and an overall warm sound. Popular borderless design and magnetic grille, extremely easy for installation and removal.

# ■ Standard Configuration

- 1 \* FBS-630A
- 1 \* User Manual

# ■ Applications

BGM in hotel/restaurant/building/conference center.

# **■** Technical Specifications

- Rated Power: 80W (AES)
- Rated Impedance: 8Ω
- Rated Voltage Power: 70V (80/60/40/20/ 10W) / 100V (80/60/40/20W) (AES)
- · Sensitivity (1W/1M): 87dB
- Coverage Angle: H110\*V110°
- Max SPL: 103dB
- · Crossover: two-way, passive
- Crossover Frequency: 3000Hz
- Installation Method: embedded/suspended

- Cut-out Size: ø246mm circle
- Installation Depth: 176mm
- · Connection: phoenix plug
- Finish: black
- Frequency Response (±3dB): 70Hz-20kHz HF: 1" tweeter with silk dome, Nd magnet, rotatable angle
  - LF: 6.5" \* 1 driver (25mm voice coil) with 80mm magnet, (PP) composite cone + NBR surround.
  - Dimensions: ø278mm\*H176mm
  - Net Weight: 3.3Kg

### ■ Installation

1 Embedded Installation


Use the cardboard to cut an opening, at 246mm outer diameter.





Turn clockwise to tighten the 4 screws around the speaker frame; or Turn counterclockwise to loosen them for speaker removal

② Suspended Installation







Attach the metal grille on top of the installed speaker.


Warning: Regardless of the installation method, the safety rope must be fastened to the keel or suspender.

### **■** Illustration



# Dimensions





# ■ Safety Instructions

To avoid electric shock, overheat, fire, radiation, explosion, mechanical risk and injury or property loss due to improper use, please read and observe the following items before use:

- 1. Please check if the power of the connected equipment matches with that of this product before operation. Adjust the volume to proper level during operation. Do not operate at over-power or high-volume level for extended time to avoid product malfunction or hearing impairment.
- 2. If there is any abnormality during use (e.g., smoke, strange odor), please kill the power switch and unplug from power source, then send the product to the local dealer for repair.
- 3. Keep this product and its accessories in a dry and ventilated area. Do not store in a humid or dusty area for extended time. Keep away from fire, rain, liquid intrusion, bumping, throwing, vibrating, or from blocking any ventilation openings, to prevent malfunction.
- 4. The product must, when installed on walls or ceilings, be fixed firmly in place at adequate strength to prevent from falling.
- 5. Please abide by safety rules during operation. Do not use the product in places prohibited by laws or regulations to avoid accident.
- 6. Do not disassemble or repair the product by yourself to avoid injury. If you have any questions or require any services, please contact our local dealer.



